



QUEST
leisure products

Welcome
to the great outdoors

Screen House Mini

• Full item instructions and extended details •

Thank you

for purchasing this product. At Quest we take every care to ensure that the product fulfils your expectations. We hope you enjoy using this product

General Use

Failure to follow the general use instructions below could lead to damage to the screen house or injury to your person. Always read and follow these instructions when using the product.


- The screen house is an external product and designed to be used outside.
- Due to the changeable weather conditions it is recommended that you always use all of the storm straps and pegging points in order to secure your screen house.
- It is also recommended that the screen house not be left unattended. Due to the nature of outdoor products along with the changeable weather conditions and differing ground conditions, many unexpected circumstances can occur. If the screen house is left unattended it could impact the performance of the screen house.
- If the screen house is going to be left unattended for an extended period of time (longer than a couple of days), we recommend to take the screen house down.
- Do not leave outside in severe weather conditions.
- Please retain all information for further reference



Quest manual download site

The quest manual download site can be found at the url below or the QR code to the left

<http://www.questleisure.com/manuals>.



Read Before Use

Extra information to ensure the safe and successful use of your screen house


- The screen house frame is made to be easily erected, but take care when erecting and taking down the screen house. Always ensure that nothing is twisted or caught in the frame.
- **NEVER** force the frame, it will open or close without the need for undue force. Applying undue force could damage the frame and would invalidate your warranty.
- Although extremely easy we recommend that you put this screen house up and down a few times at home or in an area such as a basement or garage before putting it up outside. This allows you to get used to the process before putting it up in an area that could be exposed to wind and rain.
- The screen house can be put up by one person, but it is easier to erect with two people.
- We recommend that you always peg the screen house down with both the screen house pegging points and the included storm straps.
- Always use the included the storm straps, but **DO NOT** over tighten them. The strap should be tight enough to hold the sidewall in place, it should not pull the sidewall towards the ground. Otherwise this could lead to the roof folding in during use.

Frame Diagrams

Frame diagrams for all screen house models


Screen House 4 mini Roof Frame Diagram

Code: A5503 • Diagram Version 1



Screen House 4 Mini Side Frame Diagram

Code: A5503 • Diagram Version 1



Wear , Tear and Usage

The screen house is used outdoors and thus will be subject to standard wear and tear caused by the weather and other external influences. This section lists some, but not all of the standard wear and tear you may get with your screen house.

- **Fading** : With all polyester materials used outdoors some fading or colour changing will occur. This will change depending upon how often you use it, how long it is up when you use it, what the weather is like when you use it and other external influences such as shade etc. This fading only affects the look of the material and does not affect the performance of the screen house. It is a natural process and cannot be avoided. Fading can be improved by using a proofing spray as listed in the maintenance section below.
- **Colour changing** : Similar to fading, all polyester materials used outdoors may be affected by colour changing. This is down to the amount of sun they receive whilst out, the atmospheric conditions at the time and other external factors. Colour changing is only cosmetic and does not affect the performance of your screen house.
- **U.V. Degradation** : Over time all polyester materials will break down and become brittle. This is down to the effect the sun has on the material. Your screen house is protected against this with its advanced U.V. coating, but this protection does break down over time. The time it takes will completely depend upon the weather conditions when used, such as the suns heat, cloud cover, shade and others. This is a natural process that cannot be stopped, but you can protect against it by regular cleaning and re-proofing (listed in the care and cleaning instructions).
- **Condensation** : Condensation is a natural process where moisture from the ground is drawn up and collects on the roof or sides of your screen house. Whilst this is kept to a very minimum thanks to the mesh side on your screen house, you may still get some on roof during certain conditions.

Folding and Unfolding

Details on how to use your product.

Erecting your Screen House Mini

- Remove the screen house from the carry bag and place onto the ground.
- Hold the roof hub in your hand and raise up. The frame will start to unfold and you should have the black floor on the ground. You can then place the roof hub on the ground.
- **IMPORTANT** before proceeding, ensure that the black floor is on the ground and that the frame is not tangled with any of the fabric.
- Start next to any side and pull the side centre hub towards you using the webbing strap. This will pop the side out towards you.
- Repeat this with each side and the screen house will stand up, with the roof pointing down.
- To pop the roof, simply push the centre hub up. You can do this by either going inside the screen house and pushing up, or by pulling the roof up by the loop on the top, or by pushing one of the roof beams up. The Screen House is now erected, but we always recommend pegging it down.
- Peg each corner of the screen house inside using the pegging eyelets and pegs that are included in the screen house (you can use your own pegs if you prefer).
- Once all the corners have been pegged, attach the storm straps (if not already attached) to the screen house via the stainless steel loop in the centre of the sidewall. Peg the other end of the storm strap into the ground and then tighten the strap.
- **DO NOT** over tighten the strap. The strap should be tight enough to hold the sidewall in place, it should not pull the sidewall towards the ground. If they are over tightened they can lead the roof to pop down when in use.

Taking your Screen House Mini down

- The screen house should not be taken down in high winds as it could cause damage when the storm straps and pegs are removed. If you are taking it down in high winds you must take extra care and always have more than one person present to help secure the screen house once the straps and pegs have been removed.
- Slacken the storm straps and remove the pegs from the ground, then remove all pegs from the corners
- Next pop the roof down, by pushing on one of the roof poles and the roof will pop down instantly.
- Walk outside of the screen house and push the centre of the sidewall in until it springs in and collapses. You may find it easier to hold the top left corner with one hand and push the centre in with the other.
- Repeat on every side until the entire screen house has collapsed.
- Once the screen house is laying on the ground, roll the screen house up.
- **ENSURE** that the frame is not twisted when doing this as failure to do so could cause damage to the product.
- Carefully place the screen house into the carry bag.

Storage , Care and Cleaning

Details on how to look after your product.

Storage

To help keep your product looking newer for longer and prolong the life and use of the product, we recommend that the product is covered when not in use. The screen house should never be put away wet. If it is put away wet, then it should be taken out and dried before being stored away after use. Failure to do so can cause mould growth and potential damage to your screen house.

If the product is not going to be used for an extended period (such as a winter period) we recommend that it is carefully folded away and stored in a clean, dry and free from damp location.

Care and Cleaning Instructions

Never use and harsh or abrasive cleaners or brushes when cleaning this product as the frame and fabric may be damaged when doing so. Never fold and put the product away when wet as this can trap water in the product, which can lead to mould and mildew build up.

IMPORTANT: If you have used any type of cleaner other than warm soapy water you may have damaged the U.V. coating, so we recommend reproofing the screen house as if the coating has been damaged it would lead to premature aging of the product. We recommend you use a dedicated re-proofing spray.

- **Fabric :** We recommend using a dedicated awning or tent cleaner for the fabric, if one is not available simply warm soapy water. After it has been cleaned, rinse with clean water to make sure there's no soap or cleaner left inside the fabric. Once rinsed allow the product to dry naturally before folding away and storing.
- **Frame :** First allow any dirt to dry and brush with a soft brush to remove loose dirt. Once this is done wipe the frame down with warm soapy water and a soft cloth. Once cleaned allow to dry naturally before storing away.
- **Bolts :** There are small bolts on the screen house frame mechanism. These may become loose after multiple uses, so just check that these are not loose, but never overtighten them as this could lead to damage and may invalidate your warranty.

Warranty

Details on the warranty that comes with your product.

Warranty : 12 Months (1 Year) warranty.

Warranty Claim

- In the unlikely event of a warranty claim, you must contact your retailer.
- If you have not registered your product, first fill out the registration form overleaf and take this with you when you go to your retailer.
- Take the product to your retailer that you purchased it from along with your proof of purchase and explain the issue with the retailer.
- The retailer will then check the product and get in touch with the wholesaler or manufacturer.
- The retailer will keep you informed of the progress of the claim.
- The wholesaler or manufacturer will not (unless under special circumstances) get in touch with you as all information will be passed back directly to the retailer.

Warranty Information

- This product comes with a full 12 month manufacturers defect warranty and covers any manufacturers defects for one (1) year from the date of the original purchase. It does not cover any damage occurred though:
 - The product falling, being dropped, scratched or damaged in any way.
 - The product has been technically changed by the owner or another third party
 - Improper use of the product.
 - Normal wear and tear - which includes (but is not limited to): colour fading, wearing, stretching.
 - Weather damage - which includes (but is not limited to) U.V. degradation and colour changing.
- The affected part will be replaced or repaired (manufacturers option) if they are found to be defective within the one (1) year time frame.
- The warranty will be void if the product has been subject to neglect, misuse, improper installation, misapplication, alteration or accident including, but not limited to, improper installation, maintenance or use of unauthorised parts or attachments.
- Damage caused by not following the instruction manual in full will invalidate the warranty, if this results in consequential damages, Quest will not be liable for these damages or any costs incurred due to these damages.
- Quest will not be liable for material damage or personal injury caused by improper use or if the safety instructions are not properly executed in full.
- All claims must be made through the retailer you purchased the product from and not direct with the wholesaler or manufacturer.
- Warranty claims cannot be honoured without an original dated receipt and or proof of purchase.
- By executing repairs the original warranty period of one (1) year will not be extended, nor the right to a complied new warranty. This warranty is only legal on European soil.
- This warranty does not overrule the European directive 2011/83/EU.
- This product may not be amended or changed.

Registration

You can register your Screen House online at <https://www.questleisure.com/register> or fill out the form below and send it into Quest :

Model			
Your Name		Purchase Date	
Your Email		Retailers Name	
Your Address		Retailers Address	
Additional Information			

Screen Houses

The original one person, one minute shelter, and still the best.

We have been producing the Screen House for over 6 years, longer than any others. In that time we have been improving the Screen House all the time and it means that it is the best, quickest, strongest and longer lasting than its rivals. Some of the innovation and changes cannot simply be seen, but together make our screen house perform better and last longer than the others..

Single person pitch and in less than 60 seconds

We have designed and built the Screen House to be erected by a single person. Everything about it, is catered to ensure that it can be done by one person. We test the Screen House ourselves to ensure that it can be erected by a single person. We even use our own office staff and members of the general public to test it as well. On top of this we time it ourselves and have proven time and time again that it can be erected by a single person in under one minute, so we give it both the single person pitch and 60 seconds to erect logos.

Quest Tec210 fabric

This is a modern, middleweight performance fabric. It is stronger and will last longer than its cheaper rivals. It has a high performance U.V. coating giving it the 50+ rating. It is also fully waterproof, whilst keeping the weight down making it easier to use. • Fabric Density: 210D • Waterproof rating : 2,000mm Hydrostatic Head.

U.V. 50 Plus

The Screen House has a U.V. rating of 50+, the highest available. This gives you excellent protection from the sun, especially important when the screen house is being used as a shelter for the younger ones.

Premium Hub System

We are on our 5th generation of premium hub system. This is the centre of the Screen House frame system and its single most important part. Our premium hub is simply stronger and more reliable than anyone else's. It is also repairable if anything should happen to it, ensuring piece of mind for years to come.

The best example of just how well made our screen houses are is that we use our screen house demonstrator for at least two years. During those two years it goes through approximately 15 years worth of usage as it goes up, down, up down all day long during shows and more. At the end of those two years they are still working fine and replaced only as logos and features are added.

NO Chill Pro Mesh

The screen house uses our No-chill PRO premium mesh. This mesh not only allows great views, but stops the wind chill factor allowing it to feel cooler in the sun than standard fabrics, but also warmer in the wind than its cheaper rivals. It is also stronger, lasts longer and is less prone to snags and marks than the others.





Cat No 120053

Screen House 4

The original Screen House 6. Called a 4 as it has 6 sides, this can easily be erected by a single person in under a minute. Full mesh sides built in to stop insects and combat wind chill, but allow air flow. Cooler in the sun and warmer in the wind, its the perfect quick up shelter.

The premium build quality and premium features elevates this from its rivals The hub system is extremely durable, the fabric is UV coated to help protect you and the screen hose from the suns rays and the frame is made from solid fibreglass to give it a premium feel and performance.



Cat No 120051

Screen House 6

The original Screen House 6. It is the larger cousin of the Screen House 4 and has 6 sides, but can still easily be erected by a single person in under a minute. Full mesh sides built in to stop insects and combat wind chill, but allow air flow. Cooler in the sun and warmer in the wind, its the perfect quick up shelter.

The premium build quality and premium features elevates this from its rivals The hub system is extremely durable, the fabric is UV coated to help protect you and the screen hose from the suns rays and the frame is made from solid fibreglass to give it a premium feel and performance.



Cat No A3000

Screen House 4 Pro

Based on the Screen House 4, the **PRO** version takes it two steps further. Firstly it has all the same features as the Screen House 4 and is just as easy to erect, but then it adds :

- **Zippered in full sides.** These zip down and cover the built in mesh sides with a complete fabric side. The sides also have windows on each side with an external blind.
- **Accessory Zip.** The pro model has an accessory zip around the front door allowing you to add various accessories onto your screen house.



Cat No A3005

Screen House 6 Pro

Based on the Screen House 6, the **PRO** version takes it three steps further. Firstly it has all the same features as the Screen House 6 and is just as easy to erect, but then it adds :

- **Additional Door.** The pro version of the screen house 6 has two doors, allowing you two ways in or out. **Zippered in full sides.** These zip down and cover the built in mesh sides with a complete fabric side. The sides also have windows on each side with an external blind.
- **Accessory Zip.** The pro model has an accessory zip around the front door allowing you to add various accessories onto your screen house, or even zip up to five of them together



Cat No A5503

Screen House Mini

The screen house mini, is as its names implies a mini version of the screen house. Using the same premium hub system and a smaller frame it is still extremely easy to use and pitch, it can easily be erected by a single person in under a minute. The smaller size of the mini also means a smaller and lighter pack size, but when pitched the mini is 140cm high, so easily high enough to sit under. Vents around the bottom of the unit allow air flow and the windows in the top allow extra visibility , or can be closed with the external blinds when not required. Complete with a built in PE floor that can be toggled up to create a half door at the front.

Perfect for the beach, festivals, parties at the park, fishing and more.



Cat No 120010

Instant Utility , Toilet and Shower

Whilst not strictly a screen house the instant utility is another extremely easy unit to pitch. This uses the excellent zero tension frame, which again means there is nothing to put together, nothing to inflate and nothing to tension. You simply take it out of the bag, unfold the frame and extend the legs and you are ready to go.

The unit comes with a shower shelf so it can be used as a shower unit if required and the floor can be toggled out of the way, which is an excellent idea if its being used as a shower or toilet.

Quick and easy to use, it is an excellent piece of kit to have at hand for that extra little space when required.

Accessories

A few little extras to add to your product.



Cat No 120054G (Screen House 4) : 120052G (Screen House 6)

Side Walls

Adds privacy and extra protection to your Screen House (4 and 6 only). They simply clip into each corner and velcro in place. Sold in pairs, so you can just cover a couple of sides, or every side if you wish, they can be placed over the doorway as well if required.

They can even be used in conjunction with the optional canopy pole kit to create a sun canopy area to the side of the screen house if required.

Accessories

A few little extras to add to your product.



Cat No A5504

Screen House Pro Canopy

This is an accessory for your screen house pro (fits both 4 and 6). It is a large canopy that simply zips onto the front of your screen house and gives you a large covered area to the front of your screen house..

It uses one pole at the front and comes complete with webbing straps and pegs to ensure a secure pitch.

Accessories

A few little extras to add to your product.



Cat No A5505

Screen House Pro 4 Vehicle Connector

This is an accessory for your the Screen House 4 Pro. Again this simply zips onto the front of your Screen House 4 pro and allows you to connect your screen house 4 pro to your vehicle.

Doors to the left and right allow access in and out from either side and the connector comes with a roof pole to give water run off in the roof and double beading (both 4 and 6mm) to allow direct fitting to canopies, or awning channel.

It can be connected to vehicles, or canopies between 180 and 210cm in height. As it zips on and off it does not need a drive away kit when used on a motor home or camper.

Accessories

A few little extras to add to your product.

Screen Shield (1 panel)
shown attached to Screen
Shield (3 panel)



Cat No A5510

Screen Shield (1 panel)

This is an additional panel/windbreak for your screen house pro (fits both 4 and 6). The screen shield is available in 1 panel or 3 panel lengths and zips directly to your screen house pro, or it can be used on its own (when used with at least 1 screen shield (3 panel)).

It uses the same premium hub and frame system as your Screen House making it extremely easy to erect and gives you a great protected and private area to the front of your screen house.

Accessories

A few little extras to add to your product.

Screen Shield (1 panel) and
Screen Shield (3 panel)
shown attached to Screen
House



Cat No A5512

Screen Shield (3 panel)

This is an additional panel/windbreak for your screen house pro (fits both 4 and 6). The screen shield is available in 1 panel or 3 panel lengths and zips directly to your screen house pro, or it can be used on its own (when used with at least 1 screen shield (3 panel)).

It uses the same premium hub and frame system as your Screen House making it extremely easy to erect and gives you a great protected and private area to the front of your screen house.

Welcome

to the great outdoors

www.questleisure.com



twitter.com/questleisure



facebook.com/questleisure



youtube.com/questleisure