

Welcome to your instructions



C0023: Bug Stop Magnetic door mesh



Thank you for purchasing this product. At Quest we take every care to ensure that the product fulfillies your expectations. We hope you enjoy using this product.





This is not a toy. Children should not be left unattended with the product. This item contains small parts and is not suitable for children under the age of 5.



Failure to follow the general use instructions below could lead to damage to the product or injury to your person. Always read and follow these instructions when using the product.

- Please keep these instructions, the sales receipt and, if possible, the carton with the inner packaging.
- By ignoring the safety instructions the manufacturer can not be hold responsible for any damage or injury caused by the product.
- Keep children away from the packaging material and the storage bag. There is danger of suffocation.
- Enusre that the door mesh is not close to any heat sources such as stovetops or ovens.
- Because of possible electromagnetic interference due to the magnetics, people with implanted medical devices (e.g. pace markers) should consult their doctor before using.
- Take extra caution if using wood tacks. Always keep these away from children.
- Product may not function properly if not installed correctly.
- The magnetic door mesh is not a barrier for children and pets.





Installation instructions

- Lay your magnetic door mesh flat on the floor with magnets aligned in the centre as show in the diagram on the right. Note that the top panel will have a larger gap between the magnets and the trim versus the bottom panel.
- Check each magnet to ensure they attract to each other symmetrically.
- Peel the adhesive backing off of the velcro strips and apply to the magnetic door mesh according to the diagram.
- Take Panel A and peel off velcro strip 1 and apply to center of door frame with pressure. Be sure
 to hang the screen high enough so that it does not drag on the ground. Repeat for velcro strips 2
 and 3.
- Take Panel B and peel off velcro strip 7 and apply to opposite center of door frame with pressure. Be sure to hang the screen high enough so that it does not drag on the ground.
- Repeat for velcro strips 8 and 9.
- Ensure the magnets are property aligned and connected in the center.
- Attach the remaining velcro strips in place, starting with 4 6 and then onto 10 12.

Additional Tips

- For plastic frames, only use the velcro strips.
- For wooden frames, you can also use the wood tacks provided.
- Please note, the wood tacks leave puncture holes.
- If magnets do not snap shut together, adjust the width positioning of the mesh.


Quest manual download site

The quest manual download site can be found at the url below, or the QR code below

http://www.questleisure.com/manuals.



The full instructions are also available on the Quest Leisure manuals download as shown above





Warranty: 12 Months (1 Year) warranty.

Warranty Claim

- In the unlikely event of a warranty claim, you must contact your retailer.
- If you have not registered your product, first fill out the registration form overleaf and take this with you when you go to your retailer.
- Take the product to your retailer that you purchased it from along with your proof of purchase and explain the issue with the retailer.
- The retailer will then check the product and get in touch with the wholesaler or manufacturer.
- The retailer will keep you informed of the progress of the claim.
- The wholesaler or manufacturer will not (unless under special circumstances) get in touch with you as all information will be passed back directly to the retailer.

Warranty Information

- This product comes with a full 12 month manufacturers defect warranty and covers any manufacturers defects for one (1) year from the date of the original purchase. It does not cover any damage occured though:
 - The product falling, being dropped, scratched or damaged in any way.
 - · The product has been technically changed by the owner or another third party
 - Improper use of the product.
 - Normal wear and tear which includes (but is not limited to): colour fading, wearing, stretching.
 - Weather damage which includes (but is not limited to) U.V. degradation and colour changing.
- The affected part will be replaced or repaired (manufacturers option) if they are found to be defective within the one (1) year time frame.
- The warranty will be void if the product has been subject to neglect, misuse, improper installation, misapplication, alteration or accident including, but not limited to, improper installation, maintenance or use of unauthorised parts or attachments.
- Damage caused by not following the instruction manual in full will invalidate the warranty, if this results in consequential damages, Quest will not be liable for these damages or any costs incurred due to these damages.
- Quest will not be liable for material damage or personal injury caused by improper use or if the safety instructions are not properly executed in full.
- All claims must be made though the retailer you purchased the product from and not direct with the wholesaler or manufacturer.
- Warranty claims cannot be honoured without an original dated receipt and or proof of purchase.
- By executing repairs the original warranty period of one (1) year will not be extended, nor the right to a complied new warranty. This warranty is only legal on European soil.
- This warranty does not overrule the European directive 2011/83/EU.
- This product may not be amended or changed.



This Quest Kills lantern and insect killer is part of the **Quest Kills** range of furniture. This range includes the following items that are matched with your product.





Cat No C0088

Mains powered insect killer

- High quality Mains powered Hanging loop Highly effective
- Size: 27 x 13 x 13 cm Weight: 0.55kg
- · Voltage: 220 240V · Wattage: 3W



This Quest Kills lantern and insect killer is part of the **Quest Kills** range of furniture. This range includes the following items that are matched with your product.



Cat No C0089 Fly swat

• Extendable • Display box of 12 different colours • Size: 72 x 8.5 x 1.5cm • Folded: 26 x 8.5 x 1.5cm

· Weight: 30g.



This Quest Kills lantern and insect killer is part of the **Quest Kills** range of furniture. This range includes the following items that are matched with your product.



Cat No C0090

•Battery powered • Easy to use • Portable • Size: 46 x 17 x 2.9 cm

Racquet insect killer



This Quest Kills lantern and insect killer is part of the **Quest Kills** range of furniture. This range includes the following items that are matched with your product.

Rechargable **battery** powered

Lantern
& insect
killer



Cat No C0091

Lantern and insect killer

- Lantern and inssect killer in one Can be used as just light or just insect killer• Rechargable battery
- Easy to use Hanging hook
- Size: 9 x 9 x 13 cm Weight: 0.21 kg.



This Quest Kills lantern and insect killer is part of the **Quest Kills** range of furniture. This range includes the following items that are matched with your product.



Cat No C0023

Bug stop, self close magnetic door screen

- · Magnetic self close insect screen · Snaps shut · Stops insects · Allows a gentle breeze to flow
- Installs in minutes No tools required Fits a wide selection of doors
- 100% Polyester Size: 90 x 210 cm



...outdoor leisure, home & garden









www.youtube.com/questleisure

Email: info@questleisure.com • **Web**: www.questleisure.com