


QUEST

leisure products



F0020G Fleetwood Slatted

• Full item instructions and extended details •



Thank you

for purchasing this product. At Quest we take every care to ensure that the product fulfils your expectations. We hope you enjoy using this product



General Use

Failure to follow the general use instructions below could lead to damage to the table or injury to your person. Always read and follow these instructions when using the product.

- Always ensure all legs remain in contact with the ground and take extra care when using the table on uneven ground as this can lead the table to move about.
- Children should always be under direct adult supervision when using this product and must not be allowed to operate any folding mechanisms.
- Keep hands away from folding parts to prevent entrapment. Take care when opening, closing and or adjusting this product.
- Do not force the product at any time, the product will fold away without the need for undue force.
- Do not leave outside in severe weather conditions.
- Please retain all information for further reference


Unfolding

The fleetwood slatted table folds away in seconds when not in use. To fold and unfold the table follow this procedure :

- Hold the edges of the top and unfold them upwards.
- Then push the two parts of the top together and they will meet in the middle and form the table.
- They will come together to form the table top and sit flat on top of the legs.
-

Folding

- Hold either edge of the table top and pull apart.
- Pull apart until the legs are inline and straight up.
- Then fold the table top down on either side of the legs.



Quest manual download site

The quest manual download site can be found at the url below or the QR code to the left

<http://www.questleisure.com/manuals>.



Storage , Care and Cleaning

Details on how to look after your product.

Storage

To help keep your product looking newer for longer and prolong the life and use of the product, we recommend that the product is covered when not in use.

If the product is not going to be used for an extended period (such as a winter period) we recommend that it is carefully folded away and stored in a clean, dry and free from damp location.

Care and Cleaning Instructions


Never use and harsh or abrasive cleaners or brushes when cleaning this product as the frame and table may be damaged when doing so.

Never fold and put the product away when wet as this can trap water in the frame and this could lead to rust or mould growth.

- **Tabletop** : the tabletop can be cleaned by soap and warm water. if you have any stubborn dirt on it, leave it to dry then brush off with a stiff (no hard) brush before cleaning.
- **Frame** : First allow any dirt to dry and brush with a soft brush to remove loose dirt. Once this is done wipe the frame down with warm soapy water and a soft cloth. Once cleaned allow to dry naturally before storing away.

Hang Tag Artwork

Below is a copy of the hang tag that came with your product. This is just for your reference and you should still keep the original that came with your product.





Warranty

Details on the warranty that comes with your product.

Warranty : 12 Months (1 Year) warranty.

Warranty Claim

- In the unlikely event of a warranty claim, you must contact your retailer.
- If you have not registered your product, first fill out the registration form overleaf and take this with you when you go to your retailer.
- Take the product to your retailer that you purchased it from along with your proof of purchase and explain the issue with the retailer.
- The retailer will then check the product and get in touch with the wholesaler or manufacturer.
- The retailer will keep you informed of the progress of the claim.
- The wholesaler or manufacturer will not (unless under special circumstances) get in touch with you as all information will be passed back directly to the retailer.

Warranty Information

- This product comes with a full 12 month manufacturers defect warranty and covers any manufacturers defects for one (1) year from the date of the original purchase. It does not cover any damage occurred though:
 - The product falling, being dropped, scratched or damaged in any way.
 - The product has been technically changed by the owner or another third party
 - Improper use of the product.
 - Normal wear and tear - which includes (but is not limited to): colour fading, wearing, stretching.
 - Weather damage - which includes (but is not limited to) U.V. degradation and colour changing.
- The affected part will be replaced or repaired (manufacturers option) if they are found to be defective within the one (1) year time frame.
- The warranty will be void if the product has been subject to neglect, misuse, improper installation, misapplication, alteration or accident including, but not limited to, improper installation, maintenance or use of unauthorised parts or attachments.
- Damage caused by not following the instruction manual in full will invalidate the warranty, if this results in consequential damages, Quest will not be liable for these damages or any costs incurred due to these damages.
- Quest will not be liable for material damage or personal injury caused by improper use or if the safety instructions are not properly executed in full.
- All claims must be made through the retailer you purchased the product from and not direct with the wholesaler or manufacturer.
- Warranty claims cannot be honoured without an original dated receipt and or proof of purchase.
- By executing repairs the original warranty period of one (1) year will not be extended, nor the right to a complied new warranty. This warranty is only legal on European soil.
- This warranty does not overrule the European directive 2011/83/EU.
- This product may not be amended or changed.



Blank Page

Page left intentionally blank to allow you to write your own details in.



Cat No F0016G

Fleetwood High

The taller version of the low. A table top size of 37 x 52cm. and a height of 70cm gives you a small but perfectly formed package. The table is simplicity itself, simply unfold the legs and click the table top onto the legs and you are done.



Cat No F0018G

Fleetwood Low

A table top size of 37 x 52cm. and a height of 70cm gives you a small but perfectly formed package. The table is simplicity itself, simply unfold the legs and click the table top onto the legs and you are done.



Cat No F0019G

Fleetwood Master

The largest table in the range with a table top size of 60 x 80 cm.. The master has a weatherproof solid plastic top and a powder coated steel frame. The table can be used at two different heights giving you added flexibility when needed..



Cat No F0020G

Fleetwood Slatted

The classic folding table. Simple folds out or away in seconds. The entire table is weatherproof including the frame. Quick and easy, it folds flat when not in use making it easy to carry and store.



Accessories

A few little extras to add to your product.



Cat No 124900

Quest Elite® furniture bag

- New improved colour and more durable material
- Premium quality
- Complete with its own carry bag
- Can fit multiple chairs in one bag • Universal use
- Fabric: 600D Fabric • Size: 67 x 18 x 113 cm
- Weight: 1.1 kg

Cat No 118914DP

Clamp on sun shade

- Adjustable position • U.V. protection
- Universal use • Anti glare • Can be used on chairs, tables, prams, push chairs and more
- Canopy radius: 68.5 cm • Height: 105 cm
- Folded size: 7 x 7 x 94 cm
- Weight: 0.3 kg.



Welcome

to the great outdoors

www.questleisure.com



twitter.com/questleisure



facebook.com/questleisure



youtube.com/questleisure