

# Welcome to your instructions

SP2024 : Childrens Unicorn garden set



**Thank you** for purchasing this product. At Quest we take every care to ensure that the product fulfils your expectations. We hope you enjoy using this product.



#### **General Use**

Failure to follow the general use instructions below could lead to damage to the product or injury to your person. Always read and follow these instructions when using the product.

- Always ensure that the chairs are locked in position before use.
- Always ensure all legs remain in contact with the ground and take extra care when using the chair on uneven ground as this can lead the chair to move about.
- Children should always be under direct adult supervision when using this product and must not be allowed to operate any folding or adjustable mechanisms.
- Keep hands away from folding parts to prevent entrapment. Take care when opening, closing and or adjusting this product.
- Do not force the product at any time, the product will fold away without the need for undue force.
- Do not leave outside in severe weather conditions.
- Please retain all information for further reference

#### Quest manual download site


The quest manual download site can be found at the url or the QR code below



http://www.questleisure.com/manuals.



Hang Tag Artwork : Below is a copy of the hang tag that came with your product. This is just for your reference and you should still keep the original that came with your product.



### Quest Childrens range

Chair: 36 x 38 x 50 cm. Folded: 36 x 49 x 6 cm. Max Load: 35 kg. Seat Height: 26 cm. Seat width: 29 cm. Seat weight: 0.9 kg. Umbrella Size: 96 cm. Height: 76 - 106 cm. Table height: 50 cm. Table diameter: 50 cm.



Quest manual download site www.questleisure.com/manuals

#### Full Instructions

Instructions, warranty and additional information can be found on the Quest manual download site by using the QR code or website URL above.

Warranty : 12 Months warranty.

## www.questleisure.com


Unicorn garden set Code: RDFSP2024





#### Assembly and usage instructions

- **Table assembly**: Take the two legs for the table and slide one on top of another as shown in image 1 below. Then push them into the holding positions on the underside of the table as shown in image 1.
- **Chair safety lock** : Before using the chair ensure that the safety lock is engaged as shown in image 2 below.
- **Umbrella adjustment**: The height of the umbrella can be changed by using the handle as shown in image 3. Simply push the handle up to allow adjustment, then push back down to lock in place.



Template version: 3



#### Storage

To help keep your product looking newer for longer and prolong the life and use of the product, we recommended that the product is covered when not in use.

If the product is not going to be used for an extended period (such as a winter period) we recommend that it is carefully folded away and stored in a clean, dry and free from damp location.

#### **Care and Cleaning Instructions**

Never use and harsh or abrasive cleaners or brushes when cleaning this product as the frame and fabric may be damaged when doing so.

Never fold and put the product away when wet as this can trap water in the product, which can lead to mould and mildew build up.

- Fabric (chairs and umbrella) : We recommend using a dedicated fabric cleaner for the fabric, if one is not available simply warm soapy water. After it has been cleaned, rinse with clean water to make sure there's no soap or cleaner left inside the fabric. Once rinsed allow the product to dry naturally before folding away and storing.
- Frame (chairs and umbrella) : First allow any dirt to dry and brush with a soft brush to remove loose dirt. Once this is done wipe the frame down with warm soapy water and a soft cloth. Once cleaned allow to dry naturally before storing away.
- **Table** : Simply wipe the table down with warm soapy water and a soft cloth. Once cleaned dry with a towel or soft cloth afterwards.



Warranty: 12 Months (1 Year) warranty.

#### Warranty Claim

- In the unlikely event of a warranty claim, you must contact your retailer.
- If you have not registered your product, first fill out the registration form overleaf and take this with you when you go to your retailer.
- Take the product to your retailer that you purchased it from along with your proof of purchase and explain the issue with the retailer.
- The retailer will then check the product and get in touch with the wholesaler or manufacturer.
- The retailer will keep you informed of the progress of the claim.
- The wholesaler or manufacturer will not (unless under special circumstances) get in touch with you as all information will be passed back directly to the retailer.

#### Warranty Information

- This product comes with a full 12 month manufacturers defect warranty and covers any manufacturers defects for one (1) year from the date of the original purchase. It does not cover any damage occurred though:
  - The product falling, being dropped, scratched or damaged in any way.
  - The product has been technically changed by the owner or another third party
  - Improper use of the product.
  - Normal wear and tear which includes (but is not limited to): colour fading, wearing, stretching.
- Weather damage which includes (but is not limited to) U.V. degradation and colour changing.
- The affected part will be replaced or repaired (manufacturers option) if they are found to be defective within the one (1) year time frame.
- The warranty will be void if the product has been subject to neglect, misuse, improper installation, misapplication, alteration or accident including, but not limited to, improper installation, maintenance or use of unauthorised parts or attachments.
- Damage caused by not following the instruction manual in full will invalidate the warranty, if this results in consequential damages, Quest will not be liable for these damages or any costs incurred due to these damages.
- Quest will not be liable for material damage or personal injury caused by improper use or if the safety instructions are not properly executed in full.
- All claims must be made though the retailer you purchased the product from and not direct with the wholesaler or manufacturer.
- Warranty claims cannot be honoured without an original dated receipt and or proof of purchase.
- By executing repairs the original warranty period of one (1) year will not be extended, nor the right to a complied new warranty. This warranty is only legal on European soil.
- This warranty does not overrule the European directive 2011/83/EU.
- This product may not be amended or changed.



This product is part of the **Quest Childrens** range of furniture. This range includes the following items that are matched with your product.



#### Cat No RDFSP2024

## Childrens Unicorn garden set

- Powder coated steel frame Adjustable umbrella Easy clean fabric Folds away for easy storage
- Set consists of 2 x chairs, 1 x umbrella and 1 x table
- Chair Details
- Size: 36 x 38 x 50 cm. Folded: 36 x 6 x 49 cm. Weight: 0.9 kg. Max load: 35 kg. Seat height: 26 cm.
- Seat width: 29 cm.
- Table Details
- Diameter: 50 cm. Height: 50 cm. Folded: 52 x 52 x 6 cm. Weight: 1.54 kg.
- Umbrella Details
- Diameter: 96 cm. Height: 76 106 cm. Folded: 65 x 9 x 9 cm. Weight: 0.5 kg.



This product is part of the **Quest Childrens** range of furniture. This range includes the following items that are matched with your product.



#### Cat No RDFSP2025

## Childrens Dinosaur garden set

- Powder coated steel frame Adjustable umbrella Easy clean fabric Folds away for easy storage
- Set consists of 2 x chairs, 1 x umbrella and 1 x table
- Chair Details
- Size: 36 x 38 x 50 cm. Folded: 36 x 6 x 49 cm. Weight: 0.9 kg. Max load: 35 kg. Seat height: 26 cm.
- Seat width: 29 cm.
- Table Details
- Diameter: 50 cm. Height: 50 cm. Folded: 52 x 52 x 6 cm. Weight: 1.54 kg.
- Umbrella Details
- Diameter: 96 cm. Height: 76 106 cm. Folded: 65 x 9 x 9 cm. Weight: 0.5 kg.



This product is part of the **Quest Childrens** range of furniture. This range includes the following items that are matched with your product.



Cat No RDF5203U

## Childrens Unicorn folding chair

- Powder coated steel frame Cup holder in arm Easy clean fabric Safety lock frame Packs away
- Lightweight 
  Carry bag
- Size: 60 x 29 x 63 cm Folded size: 10 x 12 x 63 cm Seat height: 29 cm Seat width: 34 cm
- Weight: 1.42 kg Max load: 35 kg.



This product is part of the **Quest Childrens** range of furniture. This range includes the following items that are matched with your product.



Cat No RDF5203T

Childrens Dinosaur folding chair

- Powder coated steel frame Cup holder in arm Easy clean fabric Safety lock frame Packs away
- Lightweight 
  Carry bag
- Size: 60 x 29 x 63 cm Folded size: 10 x 12 x 63 cm Seat height: 29 cm Seat width: 34 cm
- Weight: 1.42 kg Max load: 35 kg.



This product is part of the **Quest Childrens** range of furniture. This range includes the following items that are matched with your product.

#### Cat No 124900

#### Quest Elite® furniture bag

- New improved colour and more durable material
- Premium quality
- Complete with its own carry bag
- Can fit multiple chairs in one bag 
  Universal use
- Fabric: 600D Fabric Size: 67 x 18 x 113 cm
- Weight: 1.1 kg



#### Cat No 118914DP

#### Clamp on sun shade

- Adjustable position U.V. protection
- Universal use Anti glare Can be used on chairs,
- tables, prams, push chairs and more
- Canopy radius: 68.5 cm Height: 105 cm
- Folded size: 7 x 7 x 94 cm
- Weight: 0.3 kg.



## ...outdoor leisure, home & garden







www.youtube.com/questleisure