

# Welcome to the great outdoors

120010 Instant Utility, Shower & Toilet

• Full item instructions and extended details •

Thank you

for purchasing this product. At Quest we take every care to ensure that the product fulfils your expectations. We hope you enjoy using this product

#### General Use

Failure to follow the general use instructions below could lead to damage to the product or injury to your person. Always read and follow these instructions when using the product.

- The instant utility is an external product and designed to be used outside.
- Due to the changeable weather conditions it is recommended that you always use all of the guy lines and pegging points in order to secure your instant utility.
- It is also recommended that the instant utility not be left unattended. Due to the nature of outdoor products along with the changeable weather conditions and differing ground conditions, many unexpected circumstances can occur. If the instant utility is left unattended it could impact the performance of the instant utility.
- If the instant utility is going to be left unattended for an extended period of time (longer than a couple of days), we recommend to take the instant utility down.
- Do not leave outside in severe weather conditions.
- Please retain all information for further reference



#### Quest manual download site

The quest manual download site can be found at the url below or the QR code to the left

http://www.questleisure.com/manuals.



## **Read Before Use**


Extra information to ensure the safe and successful use of your instant utility

#### **All Models**

This is not a toy. Children should not be left unattended with the product. Injury or death may result from fire if the fabric is exposed to open flame. Take care opening or unfolding any part of this product as moving or folding parts could trap fingers.

- The utility shelter frame is made to be easily erected, but take care when erecting and taking down the utility shelter. Always ensure that nothing is twisted or caught in the frame.
- NEVER force the frame, it will open or close without the need for undue force. Applying undue force could damage the frame and would invalidate your warranty.
- Although extremely easy we recommend that you put this utility shelter up and down a few times at home or in an area such as a basement or garage before putting it up outside. This allows you to get used to the process before putting it up in an area that could be exposed to wind and rain.
- The utility shelter can be put up by one person, but it is easier to erect with two people.
- We recommend that you always peg the utility shelter down with all the available pegging points and guy lines.

# Frame Diagram Frame driagrams for the instant utility, shower and toilet.



No	Description	Code
1	Lower Leg	TBC
2	Leg Catch	TBC
3	Upper Leg	TBC
4	Leg Knuckle	TBC
5	Upper Roof Pole	TBC
6	Lower Roof Pole	TBC
7	Roof Slider	TBC
8	Roof Tensioner	TBC

Wear, Tear and Usage
The instant utility is used outdoors and thus will be subject to standard wear and tear


The instant utility is used outdoors and thus will be subject to standard wear and tear caused by the weather and other external influences. This section lists some, but not all of the standard wear and tear you may get with your instant utility.


- Fading: With all polyester materials used outdoors some fading or colour changing will occur. This will change depending upon how often you use it, how long it is up when you use it, what the weather is like when you use it and other external influences such as shade etc. This fading only affects the look of the material and does not affect the performance of the screen house. It is a natural process and cannot be avoided. Fading can be improved by using a proofing spray as listed in the maintenance section below.
- Colour changing: Similar to fading, all polyester materials used outdoors may be affected by colour changing. This is down to the amount of sun they receive whilst out, the atmospheric conditions at the time and other external factors. Colour changing is only cosmetic and does not affect the performance of your screen house.
- **U.V. Degradation**: Over time all polyester materials will break down and become brittle. This is down to the effect the sun has on the material. Your screen house is protected against this with its advanced U.V. coating, but this protection does break down over time. The time it takes will completely depend upon the weather conditions when used, such as the suns heat, cloud cover, shade and others. This is a natural process that cannot be stopped, but you can protect against it by regular cleaning and re-proofing (listed in the care and cleaning instructions).
- **Condensation**: Condensation is a natural process where moisture from the ground is drawn up and collects on the roof or sides or your instant utility. Whilst this is kept low thanks to the floor in the utility, there will still be some and this can be more if the floor of the utility is toggled up.


# Folding and Unfolding Details on how to use your product.


#### **Erecting your Instant Utility**

- Place the tent on the ground and extend the 4 legs as shown in image 1.
- Hold the central hub at a comfortable height, then gently push the upper and lower hubs together. Finally Insert the safety locking hook all as shown in image 2.
- Straighten the four corner legs and lock into position by pulling the upper and lower leg sections apart until the locking mechanism clicks into place.
- The utility is now erected, but you also need to peg each corner of the utillity and ensure all 4 guylines are also attached and pegged.












# Folding and Unfolding Details on how to use your product.


#### Taking your Instant Utility down

- IMPORTANT: First unzip the door starting, then unpeg the utillity and guylines as shown in image 5. Please be careful if this is done in the wind we recommend using two people or keeping some pegs in the ground to help keep it secure until packed away.
- Release the locks and lower each leg as shown in image 6
- · Remove safety locking hook. Disconnect the upper and lower central hubs, then the legs will automatically fold down and in as shown in image 7.
- Fold all 4 legs towards central hub. Then roll the utility away and place into carry bag.









## Storage, Care and Cleaning

Details on how to look after your product.

#### Storage

To help keep your product looking newer for longer and prolong the life and use of the product, we recommend that the product is covered when not in use. The instant utility should never be put away wet. If it is put away wet, then it should be taken out and dried before being stored away after use. Failure to do so can cause mould growth and potential damage to your instant utility.

If the product is not going to be used for an extended period (such as a winter period) we recommend that it is carefully folded away and stored in a clean, dry and free from damp location.

#### Care and Cleaning Instructions

Never use and harsh or abrasive cleaners or brushes when cleaning this product as the frame and fabric may be damaged when doing so. Never fold and put the product away when wet as this can trap water in the product, which can lead to mould and mildew build up.

**IMPORTANT**: If you have used any type of cleaner other than warm soapy water you may have damaged the U.V. coating, so we recommend reproofing the instant utility If the coating has been damaged it would lead to premature aging of the product. We recommend you use a dedicated re-proofing spray.

- Fabric: We recommend using warm soapy water and a soft sponge. If the stains are more difficult then we recommend a dedicated awning or tent cleaner for the fabric, but remember that if you use a dedicated fabric cleaner we also recomend to reproof afterwards. After it has been cleaned, rinse with clean water to make sure there's no soap or cleaner left inside the fabric. Once rinsed allow the product to dry naturally before folding away and storing.
- **Frame**: First allow any dirt to dry and brush with a soft brush to remove loose dirt. Once this is done wipe the frame down with warm soapy water and a soft cloth. Once cleaned allow to dry naturally before storing away.

## Warranty

Details on the warranty that comes with your product.

Warranty: 12 Months (1 Year) warranty.

#### **Warranty Claim**

- In the unlikely event of a warranty claim, you must contact your retailer.
- If you have not registered your product, first fill out the registration form overleaf and take this with you when you go to your retailer.
- Take the product to your retailer that you purchased it from along with your proof of purchase and explain the issue with the retailer.
- The retailer will then check the product and get in touch with the wholesaler or manufacturer.
- The retailer will keep you informed of the progress of the claim.
- The wholesaler or manufacturer will not (unless under special circumstances) get in touch with you as all information will be passed back directly to the retailer.

#### **Warranty Information**

- This product comes with a full 12 month manufacturers defect warranty and covers any manufacturers defects for one (1) year from the date of the original purchase. It does not cover any damage occurred though:
  - The product falling, being dropped, scratched or damaged in any way.
  - The product has been technically changed by the owner or another third party
  - Improper use of the product.
  - Normal wear and tear which includes (but is not limited to): colour fading, wearing, stretching.
  - Weather damage which includes (but is not limited to) U.V. degradation and colour changing.
- The affected part will be replaced or repaired (manufacturers option) if they are found to be defective within the one (1) year time frame.
- The warranty will be void if the product has been subject to neglect, misuse, improper installation, misapplication, alteration or accident including, but not limited to, improper installation, maintenance or use of unauthorised parts or attachments.
- Damage caused by not following the instruction manual in full will invalidate the warranty, if this results in consequential damages, Quest will not be liable for these damages or any costs incurred due to these damages.
- Quest will not be liable for material damage or personal injury caused by improper use or if the safety instructions are not properly executed in full.
- All claims must be made though the retailer you purchased the product from and not direct with the wholesaler or manufacturer.
- Warranty claims cannot be honoured without an original dated receipt and or proof of purchase.
- By executing repairs the original warranty period of one (1) year will not be extended, nor the right to a complied new warranty. This warranty is only legal on European soil.
- This warranty does not overrule the European directive 2011/83/EU.
- This product may not be amended or changed.

**Registration**You can register your Instant Utillity online at https://www.questleisure.com/register or fill out the form below and send it into Quest:

Model		
Your	Purchase	
Name	Date	
	;	
Your Email	Retailers Name	
Your	Dotailoro	
Address	Retailers Address	
Additional		
Information		

## Screen Houses

#### The original one person, one minute shelter, and still the best.

We have been producing the Screen House for over 6 years, longer than any others. In that time we have been improving the Screen House all the time and it means that it is the best, quickest, strongest and longer lasting than its rivals. Some of the innovation and changes cannot simply be seen, but together make our screen house perform better and last longer than the others..

#### Single person pitch and in less than 60 seconds

We have designed and built the Screen House to be erected by a single person. Everything about it, is catered to ensure that it can be done by one person. We test the Screen House ourselves to ensure that it can be erected by a single person. We even use our own office staff and members of the general public to test it as well. On top of this we time it ourselves and have proven time and time again that it can be erected by a single person in under one minute, so we give it both the single person pitch and 60 seconds to erect logos.

#### **Ouest Tec210 fabric**

This is a modern, middleweight performance fabric. It is stronger and will last longer than its cheaper rivals. It has a high performance U.V. coating giving it the 50+ rating. It is also fully waterproof, whilst keeping the weight down making it easier to use. • Fabric Density: 210D • Waterproof rating: 2,000mm Hydrostatic Head.

#### **U.V.** 50 Plus

The Screen House has a U.V. rating of 50+, the highest available. This gives you excellent protection from the sun, especially important when the screen house is being used as a shelter for the younger ones.

#### Premium Hub System

We are on our 5th generation of premium hub system. This is the centre of the Screen House frame system and its single most important part. Our premium hub is simply stronger and more reliable than anyone else's. It is also repairable if anything should happen to it, ensuring piece of mind for years to come.

The best example of just how well made our screen houses are is that we use our screen house demonstrator for at least two years. During those two years it is goes though approximately 15 years worth of usage as it goes up, down, up down all day long during shows and more. At the end of those two years they are still working fine and replaced only as logos and features are added.

#### **NO Chill Pro Mesh**

The screen house uses our No-chill PRO premium mesh. This mesh not only allows great views, but stops the wind chill factor allowing it to feel cooler in the sun than standard fabrics, but also warmer in the wind than its cheaper rivals. It is also stronger, lasts longer and is less prone to snags and marks than the others.















#### Cat No 120053 Screen House 4

The original Screen House 6. Called a 4 as it has 6 sides, this can easily be erected by a single person in under a minute. Full mesh sides built in to stop insects and combat wind chill, but allow air flow. Cooler in the sun and warmer in the wind, its the perfect quick up shelter.

The premium build quality and premium features elevates this from its rivals The hub system is extremely durable, the fabric is UV coated to help protect you and the screen hose from the suns rays and the frame is made from solid fibreglass to give it a premium feel and performance.



#### Cat No 120051 Screen House 6

The original Screen House 6. It is the larger cousin of the Screen House 4 and has 6 sides, but can still easily be erected by a single person in under a minute. Full mesh sides built in to stop insects and combat wind chill, but allow air flow. Cooler in the sun and warmer in the wind, its the perfect quick up shelter.

The premium build quality and premium features elevates this from its rivals The hub system is extremely durable, the fabric is UV coated to help protect you and the screen hose from the suns rays and the frame is made from solid fibreglass to give it a premium feel and performance.



#### **Cat No** A3000

#### Screen House 4 Pro

Based on the Screen House 4, the **PRO** version takes it two steps further. Firstly it has all the same features as the Screen House 4 and is just as easy to erect, but then it adds:

- **Zipped in full sides**. These zip down and cover the built in mesh sides with a complete fabric side. The sides also have windows on each side with an external blind.
- Accessoriy Zip. The pro model has an accessory zip around the front door allowing you to add various accessories onto your screen house.



#### Cat No A3005

#### Screen House 6 Pro

Based on the Screen House 6, the **PRO** version takes it three steps further. Firstly it has all the same features as the Screen House 6 and is just as easy to erect, but then it adds:

- Additional Door. The pro version of the screen house 6 has two doors, allowing you two ways in or out. Zipped in full sides. These zip down and cover the built in mesh sides with a complete fabric side. The sides also have windows on each side with an external blind.
- Accessoriy Zip. The pro model has an accessory zip around the front door allowing you to add various accessories onto your screen house, or even zip up to five of them together



#### **Cat No** A5503

#### Screen House Mini

The screen house mini, is as its names implies a mini version of the scren house. Using the same premium hub system and a smaller frame it is still extremely easy to use and pitch, it can easily be erected by a single person in under a minute. The smaller size of the mini also means a smaller and lighter pack size, but when picthed the mini is 140cm high, so easily high enough to sit under. Vents around the bottom of the unit allow air flow and the windows in the top allow extra viabaility, or can be closed with the external blinds when not required. Complete with a built in PE floor that can be toggled up to create a half door at the front.

Perfect for the beach, festivals, parties at the park, fishing and more.



#### **Cat No** 120010

#### Instant Utility, Toilet and Shower

Whilst not strictley a screen house the instant utility is another extremely easy unit to pitch. This uses the excellent zero tension frame, which agian means there is nothing to put together, nothing to iunflate and nothing to tension. You simply take it out of the bag, unfold the frame and extend the legs and you are ready to go.

The unit comes with a shower shelf so it can be used as a shower unit if required and the floor can be toggled out of the way (exceleint idea if its being used as a shower or toilet.

Quick and easy to use, it is an excellent piece of kit to have at hand for that extra little space when required.

A few little extras to add to your product.



Cat No 120054G (Screen House 4): 120052G (Screen House 6)

#### Side Walls

Adds privacy and extra protectrion to your Screen House (4 and 6 only). They simply clicp into each corner and velcro in place. Sold in pairs, so you can just cover a couple of sides, or every side if you wish, they can be placed over the doorway as well if required.

They can even be used in conjunction with the optional canopy pole kit to create a sun canopy area to the side of the screen house if required.

A few little extras to add to your product.



#### **Cat No** A5504

#### Screen House Pro Canopy

This is an accessory for your screen house pro (fits both 4 and 6). It is a large canopy that simply zips onto the front of your screen house and gives you a large covered area to the front of your screen house..

It uses one pole at the front and comes complete with webbing straps and pegs to ensure a secure pitch.

A few little extras to add to your product.



#### **Cat No** A5505

#### Screen House Pro 4 Vehicle Connector

This is an accessory for your the Screen House 4 Pro. Again this simply zips onto the front of your Screen House 4 pro and allows you to connect your screen house 4 pro to your vehicle.

Doors to the left and right allow access in and out from either side and the connector comes with a roof pole to give water run off in the roof and double beading (both 4 and 6mm) to allow direct fitting to canopies, or awning channel.

It can be connected to vehicles, or canopies between 180 and 210cm in height. As it zips on and off it does not need a drive away kit when used on a motorhome or camper.

A few little extras to add to your product.

Screen Shield (1 panel) shown attached to Screen Sheld (3 panel)



#### **Cat No** A5510

### Screen Shield (1 panel)

This is an additional panel/windbreak for your screen house pro (fits both 4 and 6). The screen shield is available in 1 panel or 3 panel lengths and zips directly to your screen house pro, or it can be used on its own (when used with at least 1 screen shield (3 panel)).

It uses the same premium hub and frame system as your Screen House making it extreely easy to erect and gives you a great protected and private area to the front of your screen house.

A few little extras to add to your product.

Screen Shield (1 panel) and Screen Sheld (3 panel) shown attached to Screen House



#### **Cat No** A5512

#### Screen Shield (3 panel)

This is an additional panel/windbreak for your screen house pro (fits both 4 and 6). The screen shield is available in 1 panel or 3 panel lengths and zips directly to your screen house pro, or it can be used on its own (when used with at least 1 screen shield (3 panel)).

It uses the same premium hub and frame system as your Screen House making it extreely easy to erect and gives you a great protected and private area to the front of your screen house.



www.questleisure.com



twitter.com/questleisure



facebook.com/questleisure



youtube.com/questleisure